

**Required Tools: (Not included)**

- A. 3 mm Allen Wrench
- B. 5 mm Allen Wrench

**⚠ WARNING**

**⚠ CAUTION:** To avoid potential shock or other injury, turn power switch OFF and disconnect charger before conducting any assembly or maintenance procedures. Failure to follow these steps in the correct order may cause irreparable damage.

**Step 1**

Using a 5 mm Allen wrench, loosen the bolts from the collar clamp and pull the stem from the fork.

**Step 2**

Disconnect the two (2) connectors from the handlebar, remove the rubber plug from the fork, and pull the wire with the squared connector to unplug the front light.



### Step 3

Using a 3 mm Allen wrench, loosen and remove the two (2) bolts that secure the headlight in place. Remove headlight and make sure the fork is straight to allow you to remove the cable and connector.



### Step 4

Reverse the steps to install the new headlight.

**ATTENTION: Charge battery 8 hours before using.**