



**RSF350**  
**HANDLEBAR GRIPS REPLACEMENT**  
PART NUMBER: W15128190053

**Required Tools: (Not included)**

- 3 mm Allen wrench
- 5 mm Allen wrench
- Small flat screwdriver

**⚠ WARNING**

**⚠ CAUTION:** To avoid potential shock or other injury, turn power switch OFF and disconnect charger before conducting any assembly or maintenance procedures. Failure to follow these steps in the correct order may cause irreparable damage.

**Step 1**

Using a 3 mm Allen wrench, loosen the set screw from the throttle. Remove the throttle from the grip.



**Step 2**

Using a 5 mm Allen wrench, loosen the bolt on the brake lever. Move the lever away from the grip.



### Step 3

Insert the blade of a small flat screwdriver in between the grip and the handlebar. Using soapy water or lubricant, apply a few drops and pull the grips out from the handlebar.



### Step 4

Install the new handlebar grips then reverse steps 1 through 3.

**ATTENTION: Charge battery 12 hours before using.**