

**Required Tools: (Not included)**

- A. Phillips screwdriver
- B. Small flat screwdriver
- C. Small pointy object

**⚠ WARNING**

**⚠ CAUTION:** To avoid potential shock or other injury, turn power switch **OFF** and disconnect charger before conducting any assembly or maintenance procedures. Failure to follow these steps in the correct order may cause irreparable damage.

**Step 1**

Using a Phillips screwdriver, remove six (6) screws located on the back of the battery cover.

**Step 2**

Remove the battery cover from the front of the unit and disconnect the battery and charger port from the controller.



### Step 3

Using a small flat screwdriver, remove the black wire that connects to the power switch by pressing the tab on the side of the connector and pulling the wire at the same time.



### Step 4

Using a small pointy object, remove the silicone around the charger port. Loosen the lock nut from the charger port and push it out from the cover.



### Step 5

To install a new charger port, reverse steps 1-4.

- Put the new charger port in place.
- Reconnect all connectors from the controller.
- Note: The wires that connect to the power switch need to be connected in this sequence: the black wire from the charger port connects to the gold-colored prong, the blue wire from the controller connects to the middle prong, and the red wire from the controller connects to the right-side corner prong.
- Put the battery cover back in place.
- Reattach the battery cover screws.

**ATTENTION: Charge battery 12 hours before using.**