



**HOVERTRAX BRIGHTS
LED LIGHTS REPLACEMENT**
PART NUMBER:W15156234521

Required Tools: (Not included)


- Phillips Screwdriver

⚠ WARNING

⚠ CAUTION: To avoid potential shock or other injury, turn power switch **OFF** and disconnect charger before conducting any assembly or maintenance procedures. Failure to follow these steps in the correct order may cause irreparable damage.


Step 1

Turn the Hovertrax upside down. Use a Phillips screwdriver to loosen all the screws securing the left and right lower covers.




Step 2

Find the power wire and disconnect the connector.



Step 3

Disconnect the connector between the LED lights and controller. Then you can remove the LED lights.



Step 4

Insert new LED lights, then reverse steps 1 through 3.

ATTENTION: Charge battery 12 hours before using.