




Required Tools: (Not included)

- A. Phillips screwdriver
- B. 5 mm Allen wrench
- C. 2.5 mm Allen wrench
- D. Flat screwdriver
- E. Pliers

WARNING

 CAUTION: To avoid potential shock or other injury, turn power switch OFF and disconnect charger before conducting any assembly or maintenance procedures. Failure to follow these steps in the correct order may cause irreparable damage.

Step 1

Using a Phillips screwdriver, remove two (2) screws located under the seat at the back of the unit.



Step 2

Lift and pull back on the seat to remove.



Step 3

Locate and disconnect the brake lever switch from the controller.



Step 4

Using a 5 mm Allen wrench, loosen the bolt from the clamp on the brake lever.



Step 5

Using a 2.5 mm Allen wrench, loosen the set screw from the display. Move the display and brake lever away from the grip.



Step 6

Using a flat screwdriver, insert the blade between the handlebar and the grip. Apply WD-40® or soapy water and remove the grip. Slide out the display and brake lever.



Step 7

Using pliers, remove the end cap from the brake cable.



Step 8

Using a 5 mm Allen wrench, loosen the bolt that holds the brake cable in place. Remove the cable from the caliper.



Step 9

To install new left brake lever, reverse steps 1-8.

ATTENTION: Charge battery 6 hours before using.