




EN Read and understand this guide before using product.
ES Es imprescindible leer y comprender esta guía antes de usar el producto.



Razor®

Crazy Cart Shuffle™



1-5




6-7



8-9


www.razor.com/mx

Hecho en China




3

5 mm





4




5

5 mm







6




7

5 mm







8




9




10







11



12









5

EN How to ride the Crazy Cart Shuffle.
ES Cómo conducir el Crazy Cart Shuffle.



GO





EN



WARNING. To avoid serious injury:

- Use only under the direct supervision of an adult.
- Adult supervisors must ensure that children are properly instructed in the use of the Crazy Cart Shuffle go kart.
- NEVER ride in traffic, on roads or near motor vehicles, where serious accidents can happen. Watch your surroundings for pedestrians, bike, skateboard, scooter and other riders. Use in areas free from hazards such as poles, hydrants, and parked cars.
- This toy has no brake.
- Place your feet on the ground and lower the Drift Bars to slow and stop. Make certain feet are placed on the sides (not in front of the Foot Bar before dismounting to either side). Do not step out of Crazy Cart Shuffle until unit has come to a complete stop.
- Never use near streets, swimming pools, hills, or steps. Use on smooth, dry, level ground. Ride in places that allow you to improve your skills and do not ride on loose debris (such as rocks, gravel or sand), or speed bumps.
- Always wear shoes when using the go kart.
- Allow only one rider at a time on the go kart.
- Like any other moving product, riding a go kart can be a dangerous activity and may result in injury even when used with proper safety precautions.
- Do not ride at night or in low visibility conditions.
- The toy should be used with caution to avoid falls or collisions causing injury to the user or third parties.
- Must be assembled by an adult.

Age and Weight Limits

- Not for children under age 4.
- Maximum rider weight 68 kg.

Protective Equipment Should be Worn

- Wear protective equipment, such as helmet, elbow and knee pads.

Failure to use common sense and heed the above warnings further increases risk of serious injury. Use at your own risk and with appropriate and serious attention to safe operation. Use caution.

Maintenance

- Inspect wheels and general condition of your go kart before riding.
- The go kart wheels and bearings are maintenance free, under normal circumstances and conditions.
- Regularly check that the various screwed parts are tight.
- Use only authorized Razor replacement wheels.
- No modifications can be made that can impair safety.
- Wipe with a damp cloth to remove dirt. Do not use alcohol, alcohol-based or ammonia-based cleaners as they may damage the plastic components.
- If repairs are needed, bring product to a qualified technician.

DO NOT DISCARD THIS INSTRUCTION MANUAL AS IT MAY CONTAIN IMPORTANT USER INFORMATION.

ES



! ADVERTENCIA. Para evitar lesiones graves:

- Usar únicamente bajo la supervisión directa de un adulto.
- Los adultos responsables deben asegurarse de que se haya explicado de forma adecuada a los niños cómo usar el kart Crazy Cart Shuffle.
- NO patine NUNCA con tráfico, en carreteras o cerca de vehículos motorizados, donde puedan provocarse accidentes graves. Prestar atención a los peatones, ciclistas, usuarios de patinetes y escúteres y otros conductores que pudieran estar alrededor. Usar en zonas exentas de peligros tales como postes, bocas de incendio y coches estacionados.
- Este juguete no tiene frenos.
- Colocar los pies en el suelo y bajar las barras de derrape para reducir la velocidad y detenerse. Asegurarse de colocar los pies a los lados de la barra (no delante) antes de bajarse del kart. No levantarse del asiento hasta que el Crazy Cart Shuffle se haya detenido completamente.
- No usar nunca cerca de calles, piscinas, pendientes ni peldaños. Utilizar sobre superficies llanas, secas y niveladas. Patine en lugares donde pueda mejorar sus habilidades y nunca sobre escombros (como rocas, grava o arena) ni sobre badenes.
- El kart debe utilizarse siempre con los zapatos puestos.
- No permitir que más de un niño se monte en el kart al mismo tiempo..
- Como cualquier otro producto de movilidad, montar en un kart puede ser una actividad peligrosa y ocasionar lesiones, aun cuando se tomen las precauciones de seguridad correspondientes.
- No conduzca de noche o cuando la visibilidad sea limitada.
- Este juguete debe usarse con precaución para evitar caídas o colisiones que causen lesiones al usuario o a terceros.
- Debe ser montado por un adulto.

Límite de edad y peso

- No indicado para niños menores de 4 años.
- Peso máximo del conductor: 68 kg.

Recomendación de usar equipo de protección

- Utilice equipo de protección, como casco, coderas y rodilleras.

Si no se usa el sentido común y presta atención a las advertencias anteriores puede aumentar el riesgo de sufrir lesiones graves. Úsese bajo su propio riesgo y con la atención correcta y sería para una operación segura. Tenga precaución.

Mantenimiento

- Inspeccionar las ruedas y el estado general del kart antes de usarlo.
- En circunstancias y condiciones normales, las ruedas y los rodamientos del kart no requieren mantenimiento.
- Comprobar periódicamente que las distintas piezas atornilladas estén bien apretadas.
- Usar únicamente ruedas de recambio Razor autorizadas.
- No efectuar modificaciones que puedan afectar la seguridad.
- Limpiar con un trapo húmedo para quitar la suciedad. No usar alcohol ni limpiadores a base de alcohol o amoníaco, pues pueden dañar los componentes de plástico.
- Si fuera necesario reparar el producto, llévelo a un técnico especializado.

NO DESECHE ESTE MANUAL DE INSTRUCCIONES, YA QUE PUEDE CONTENER INFORMACIÓN ÚTIL PARA EL USUARIO.

Printed in China for Razor USA LLC.

Copyright ©2003-2025 Razor USA LLC. All rights reserved. Razor®, the Razor logo design and Crazy Cart® are among the registered trademarks of Razor USA LLC and/or its affiliated companies in the United States and/or select foreign countries. Crazy Cart® Shuffle™ logo design is a trademark of Razor USA LLC.



www.razor.com/mx
Hecho en China

26L+CAN_250919