

Required Tools: (Not included)

- Phillips Screwdriver

⚠ WARNING

⚠ CAUTION: To avoid potential shock or other injury, turn power switch **OFF** and disconnect charger before conducting any assembly or maintenance procedures. Failure to follow these steps in the correct order may cause irreparable damage.

Step 1

Using a Phillips screwdriver, remove the three screws on the right-side battery cover with the speed switch.

**Step 2**

Remove the battery cover, then disconnect the speed switch connector from the controller.



Step 3

Using a Phillips screwdriver, remove the two screws on the rear of the speed switch, then pull the switch out of the battery cover.



Step 4

Install a new speed switch, then reverse steps 1 through 3.

ATTENTION: Charge battery 12 hours before using.