



RAMBLER MD1
SPEED SWITCH REPLACEMENT
PART NUMBER:W25141001280

Required Tools: (Not included)


- Phillips Screwdriver

⚠ WARNING

⚠ CAUTION: To avoid potential shock or other injury, turn power switch **OFF** and disconnect charger before conducting any assembly or maintenance procedures. Failure to follow these steps in the correct order may cause irreparable damage.


Step 1

Using a Phillips screwdriver, remove the six (6) screws on the battery cover.




Step 2

Locate and disconnect the speed switch from the controller.




Step 3

Using a Phillips screwdriver, remove the two (2) screws on the speed switch cover.



Step 4

Remove the speed switch.



Step 5

Insert a new speed switch, then reverse steps 1 through 4.

ATTENTION: Charge battery 12 hours before using.