



**RSF350 KICKSTAND
REPLACEMENT INSTRUCTIONS**
PART # W15128001028

Required Tool: (Not included)

- 6 mm Allen wrench

⚠ WARNING

⚠ CAUTION: To avoid potential shock or other injury, turn power switch OFF and disconnect charger before conducting any assembly or maintenance procedures. Failure to follow these steps in the correct order may cause irreparable damage.

Step 1

Rest the unit on its side. Using a 6 mm Allen wrench, loosen and remove the hex bolt that keeps the kickstand on the frame.



Step 2

Reverse the steps to install.

ATTENTION: Charge battery 12 hours before using.

250424_R