



RSF350
BATTERY REPLACEMENT
PART NUMBER: W15120040003

Required Tools: (Not included)


- Phillips screwdriver
- 5 mm Allen wrench

⚠ WARNING

⚠ CAUTION: To avoid potential shock or other injury, turn power switch OFF and disconnect charger before conducting any assembly or maintenance procedures. Failure to follow these steps in the correct order may cause irreparable damage.

Step 1

Using a Phillips screwdriver, loosen and remove seven (7) screws from the battery cover on the side with the charger port.



Step 2

Pull the battery cover off and set aside.



Step 3

Locate and disconnect the battery from the controller.



Step 4

Using a 5 mm Allen wrench, loosen and remove two (2) hex bolts located on the bottom of the unit.



Step 5

Remove the battery bracket from the battery.



Step 6

Remove the two (2) batteries from the unit.



Step 7

Install the new battery, then reverse steps 1 through 6.

ATTENTION: Charge battery 12 hours before using.