

Required Tools: (Not included)

- 5 mm Allen Wrench
- Flathead Screwdriver
- 10 mm Open-end Wrench
- Pliers

⚠ WARNING

⚠ CAUTION: To avoid potential shock or other injury, turn power switch **OFF** and disconnect charger before conducting any assembly or maintenance procedures. Failure to follow these steps in the correct order may cause irreparable damage.

Step 1

Using a 5 mm Allen wrench, loosen the screw securing the brake lever to the handlebar, then slide the brake lever away from the grip.

**Step 2**

Insert the tip of a flathead screwdriver between the grip and the handlebar. Apply a few drops of WD-40 or soapy water, then pull the grip and brake lever off the handlebar.



Step 3

Using pliers, remove the end cap from the end of the brake cable.



Step 4

Using a 10 mm open-end wrench, loosen the lock nut securing the brake cable, then slide the cable out.



Step 5

Using a 5 mm Allen wrench, loosen and remove the bolts securing the V-brakes to the fork, then pull the brakes off the fork.



Step 6

When installing the brakes, ensure the pin on the spring tensioner sits in the center hole on the fork.



Step 7

install a new brake, then reverse steps 1 through 6.

ATTENTION: Charge battery 12 hours before using.