

Required Tools: (Not included)

- T25 driver
- Phillips screwdriver
- Two (2) 19 mm wrenches

⚠ WARNING


⚠ CAUTION: To avoid potential shock or other injury, turn power switch OFF and disconnect charger before conducting any assembly or maintenance procedures. Failure to follow these steps in the correct order may cause irreparable damage.

Step 1

Using a T25 driver, remove the six (6) screws from the deck and pull the deck away from the unit.

**Step 2**

Locate and disconnect the rear fender connector from the controller.



Step 3

Using two (2) 19 mm wrenches, loosen the lock nuts from the rear axle and slide the rear wheel down and out from the frame.



Step 4

Lift the plastic cover on the rear fender to expose two (2) screws. Using a Phillips screwdriver, remove the two (2) screws that hold the rear fender onto the frame.



Step 5

Slide back the rear fender out from the frame.



Step 6

Install the new rear fender, then reverse steps 1 through 5.

ATTENTION: Charge battery 5 hours before using.